


Honeywell

EDA50-HB Quick Start Guide




EDA50-HB-QS-R (Rev A)

1



2

Connection Description



1. Connect Micro USB to USB charging port on base;
2. Put the device onto the base in the arrow direction;
3. Turn on the power, and the indicator ScanPal EDA50™ will light to show it is charging.



Please use the power adapter and USB cable along with the device.

Honeywell

3

Technical Support

For contact information related to technical support, after-sales service and maintenance, please visit www.honeywellaidc.com.

User documentation

For the local version of the documentation, please visit www.honeywellaidc.com

Patent

For patent information, please refer to www.honeywellaidc.com/patents.

Warranty period

For warranty information of your product, please log onto www.honeywellaidc.com/warranty-information.

Disclaimer

Honeywell International Inc reserves the right to alter specifications or any other information without prior notice. Readers should feel free to consult Honeywell International Inc. on whether such an alternation has been made. The information contained in this documentation is not part of Honeywell International Inc. commitments, and Honeywell International Inc. shall not be deemed liable for any loss, whether direct or indirect, caused possibly by the technical or editorial errors or omissions.

This documentation contains proprietary information protected by copyright. All rights reserved. Without prior written consent of Honeywell International Inc., no part of this documentation shall be photocopied, reproduced, or translated into another language.

©2016 Honeywell International Inc.
Website: www.honeywellaidc.com